



## 1322 FERTILIZER FEEDER

TROUBLE	CAUSE	CHECK	CORRECTION
MACHINE WON'T RUN	POWER FAILURE	CHECK OUTLET POWER	USE DIFFERENT OUTLET
		CHECK ALL WIRE CONNECTIONS	TIGHTEN CONTACTS BACK
		MAKE SURE SWITCH IS "ON" POSITION	SWITCH ON
		CHECK VARIABLE SPEED CONTROL	TURN SPEED UP
		CHECK VOLTAGE ON BOTH SIDE OF SWITCH	REPLACE SWITCH
		CHECK INPUT A/C VOLTAGE ON DC CONTROLE BOARD "L1&L2"	REFER TO ABOVE IF NO POWER
		CHECK OUTPUT D/C VOLTAGE ON DC CONTROLE BOARD "A1&A2"	IF NO DC VOLTAGE -NEW DC CONTROL BOARD IF CORRECT DC VOLTAGE-NEW GEARMOTOR
BELT WON'T TURN	WORN PULLEY	CHECK KNURLING ON DRIVE PULLEY	REPLACE PULLEY
	LOOSE BELT	CHECK TENSION OF BELT	TIGHTEN BELT
	PULLEY SEIZED	VISUALLY INSPECT BOTH PULLEYS	REPLACE PULLEY REPLACE BEARINGS
BELT WON'T STAY ON TRACK	OFFSET PULLEY	MEASURE DISTANCE EACH SIDE OF TAKE UP	ADJUST AS NEEDED
	BUILD UP IN V-GROOVE	LOOSEN TAIL PULLEY AND VISUALLY INSPECT	LOOSEN TAKE UP AND REMOVE DEBRIS
	V-GUIDE OFF BACK OF BELT		REPLACE BELT
LIGHT NOT WORKING	SENSOR MALFUNTION	CHECK IF SENSOR IS READING	REPLACE SENSOR
			CALL KASE FOR INSTRUCTIONS ON HOW TO TROUBLE SHOOT SENSOR

**\*\*\*\*\*WILL NEED VOLTAGE METER AND/OR SCREWDRIVER FOR MOST TROUBLESHOOTING\*\*\*\*\***

For Parts Quotes and/or Orders Call Kase (254)694-5846